



dB2-4WALLS®

SOUND CONTROL *solutions*

INSTALLATION STEPS IF YOU ARE INSTALLING ON TOP OF DRYWALL ON AN EXISTING FINISHED WALL



GLUE

Trowel vinyl adhesive on the wall. Make sure to apply full coverage to the area where the sheet will be hung.



HANG

Hang on wall. Use staples up on top for additional support but may not be necessary.



ALIGN

Align seams and join together. To reduce appearance of seams—use a typical drywall joint compound in the seam, let dry, smooth and finish.



PAINT

Paint to desired color. Add your wall hangings. Enjoy your privacy. Enjoy the quiet ambience the way it is supposed to be heard.